

KeyCovers Stock code, BCK Ref. & Dims.	Brand	Model
<b>173.412 KC2</b> 684 x 170/252 x 35mm	BCK	GARAGE KEY, MK49, X-TREME CONTROL, TQ49
	CASIO	Ma100/101.120/130/150/201/220, Pa31/81/480, RaP1, Sa20/21/35/38/39/45/67/75, SK60/65, Ta10, va10
	M-AUDIO	OZONE, OXYGEN 8, E-KEYS
	YAMAHA	PSS12/14/15/16/21/26/190/280/290/390,CBX-K1
<b>173.413 KS3</b> 878 x 253/287 x 40mm	BCK	MIDI MaSTER PLUS, MIDI PLUS, MIDI PRo, MIDI CoMPoSER, MIDI STaRT, MIDI STUdIo 2, MIDI Con TRoL 2, MC2
	CASIO	Ca100/110, CT380/395, CTK50/100/120/150/200/230, DM100, MT640, MT740, Sa65
	FATAR	STUDIO 49
	KORG	PROPHECY, K49
	M-AUDIO	AXIOM 49, KEYSTATION 49E, RADIUM 49, OZONIC, OXYGEN 49
	YAMAHA	PSR3/6/8/16/73/74/75/125, PSS31/680/760/780/790/795, CBX-K2
<b>173.415 KC4</b> 973 x 266/398 x 60mm	BCK	MK61, PRO 61, MIDI PLUS 61/61U
	CASIO	CTK80/451/481/491/495/496/519/531/541/551/571/560L/573/591/611/620L/631/651/671/680/691/700/731/800/900, LK30/35/43/45/50/55/60/65/705/90Tv/93Tv, CTX450, MT750
	GENERAL	CD1/2/3/10/20/30, gK310/330/340/350, WK1/1000
	KORG	X5, XD5
	M-AUDIO	RADIUM 61
	ROLAND	C180, E15/16/28/35.400R, EM10/15/20/25, 150R, EP3/5, JP8000, Jv30, JX30, JX3P, SK50, Eg101, Sh201, vP550
	TECHNICS	KC200/211/600/611, Kn300/470/500/550/570/650/700/750, MB100
	YAMAHA	an1X, CS1X/2X, DJX, DX21, EZag20/30/150/250i, PSR77/100/160/170/172/175/195/202/225gM/206/215/220/225/270/273/275/280/290/292/293/295/340/350/410/420/540/630/640/730/740/1000/1500/2000/3000/K1, PSRa300/1000, PSRE203/303, So3/3SL, yPT200/300
<b>173.416 KC5</b> 1060 x 279/448 x 60mm	CASIO	CPS120, CTK560L/620L/631/731/750/1000, CT450/460/625/6000, hT3000/6000, vZ1
	ENSONIQ	TS10, ASR10
	KORG	Pa50, TRITon LE61, i5s5, X3, M1, 01W, T3, T3EX, WS, Wav ESTaTion ES, n5, TRITon , TR6/76
	ROLAND	E100, EM30/50/55/550R, JD800, va3, v Syn Th, Eo9/12/14/20/36/38/50/66/68/300, EXR3/35/55/75/40R, Fan To M S/X6/Xa, gW7, JUno D/g, Jv35/50/80/180, JW50, JX1/305, RS5/50/70, XP10/30/50/60
	TECHNICS	Kn501/600/700/701/720/770/800/901/920/930/1000/1200/1400/1500/1600/2000/2400/2600/3000/3500/5000/6000/6500/WSa1
	YAMAHA	CS6X, ES6, PSR1100/2100/4000/7000/8000, DSR500/1000/2000/3000, DX7, Mo6, MoTlv6, MoTlv S30, Sy77/85, PSR28, v50
<b>173.418 KC6</b> 1175 x 303/430 x 60mm	CASIO	CK30, CTK711EX/811EX, CPS7, CTK930, hTX10/50, LK73/80, MZ2000, WK1200/1300/1350/1500
	MUSIC	WK2/3/4/6/B, WK2000hD/2000SE, WS2, WX2, EQUIno X61, PRP8, gEnESyS, gEnESyS PRo, gEnESyS S
	KETRON	KETRon X1, XD9, SD1, SD5, vEga
	KORG	CX3, iS40/50, Pa1X/60/80, TRITon STUdIo 61, i3, i30, TRInITy, TRInITy PLUS, TRInITy v3, iX300, n364, Z1, TRITon EXTREME 61
	ROLAND	E56/70/86/96/500/600, EM2000, EP7/75/76/77/760, g600, KR33/55, RD200, EP7-LLE, vK7/8
	TECHNICS	KN7000
	YAMAHA	DgX200/202/300/305/203, PSR6000/9000, QS300, W7, yPP50/100, EX7, TyRo S, TyRo S 2, yFP70
<b>173.419 KC7</b> 1267 x 270/472 x 60mm	CASIO	CPS505/700/720, WK1600/1630/1800/3000/3200/3500/3700
	ENSONIQ	KS32, SQ2
	MUSIC	PRoMEga, PRoMEgE 2, S3, SX3, SK76/760, WK1600/1800
	KORG	TRITON PRO, 01 WPRO, TRITON LE76
	ROLAND	a30/33/37/50/70, D70, DISCOV ER 5, E60/80, g800/1000, EXR7, Fa76, Fan To M, Fan To M X7, Jv90/1000, KR100/500, RD250, va5/7/76, XP80
	TECHNICS	PR100/110
<b>173.421 KC8</b> 1385 x 338/470 x 60mm	YAMAHA	CLP152S, DgX205/EX5, PDP100, MoTlv7, PSR2500/3500/4500/4600/6700/9000PRo/PSRgX76, MoTlv ES7, Sy99, yPP45/55, yPR50
	CASIO	aP21/24/33/38/45/80R, CPS805/85, PL40R, PS20, PX100/110LB/110DK/300/300L/310/400R/500L/700
	FATAR	SL990, STUdIo 900, STU2001, STU90+, STUdIo Log IC 880
	MUSIC	PRo2, PoMEga 3, SK88/880, RPBaSIC, RP8/15, EQUIno X76
	KAWAI	CL20, Cn270, ES5, ES4, SLB110, ES1/3, L1, MP4
	KORG	C3200/6500, EC120/150/350, SgPRoX, Sg1D, SP250, n1, TRITon STUdIo 76, i2, X2, TRInITy PRo, TRInITy v3 PRo, n264, SP100/200/300/500, Pa1X PRo, TRITon EXTREME 76
	ROLAND	a80, EP9E/85/97, FP1/2/3/5/8/9, F30/30E/50/90/100, g70, KR350/650, KF7/90, MP500BW, RD100/150/170/600, vR760
	TECHNICS	PC8/12/25/26, PX201M, P30/50, SP30
	YAMAHA	CLP80/153S, DgX500/505, PFP100, PF85, P60/60S/70/70S/80/90/120/120S/140/140S/150/200/250/300, PDP400, Mo8, S80/90, So8, W5, yDP113/123/223, yPP200