

## Yamaha Keyboard Cover Range

Model Number - Large White Logo	Model Number - Small Purple Logo	Range Covered
DC1A	DC1A-PURP	PSR 140 / 160 / 170 / 263 / YPT255
DC2A	DC2A-PURP	PSR 240 / 260 / 270 / 280 / EZ20 / EZ30
DC5A	DC5A-PURP	PSR 4000 / 7000 / 8000
DC6A	DC6A-PURP	PSR 9000
DC9A	DC9A-PURP	GX76
DC10A	DC10A-PURP	YPP100
DC11A	DC11A-PURP	DGX 200 / 205 / 220 / 230 / 300 / 305 / YPG235
DC12A	DC12A-PURP	DGX 500
DC13A	DC13A-PURP	PSR9000 PRO
DC14A	DC14A-PURP	P60 / P70 / P120 / P140 / P155
DC15A	DC15A-PURP	P80 / P90
DC16A	DC16A-PURP	Tyros 1 & 2 Cover - Printed "TYROS" (NOT PURPLE)
DC16B	DC16B-PURP	Tyros 3 & 4 Cover - Printed "TYROS" (NOT PURPLE)
DC16C	DC16C-PURP	Tyros 5 Cover (61 Note) - Printed "TYROS 5" (NOT PURPLE)
DC16D	DC16D-PURP	Tyros 5 Cover (76 Note) - Printed "TYROS 5" (NOT PURPLE)
DC16E	DC16E-PURP	Genos Keyboard - Printed "GENOS" (NOT PURPLE)
DC16SET-G	DC16SET-G-PURP	Set of Three Genos Speaker Covers
DC16SET-T	DC16SET-T-OURP	Set of Three Covers for all Tyros Speakers (all Models)
DC17A	DC17A-PURP	PF500 / PF1000
DC18A	DC18A-PURP	EZ150 / 250 / 172 / 275 / PSR E253 / PSR F50 / F51
DC19A	DC19A-PURP	PSR295 / 403 / 413 / 423 / 433 / 450 / 495 / 520 / 530 / 540 / 620 / 630 / 640 / 730 / 740 / 1000 / 2000 / 1100 / 1500 / 2100 / 3000 / K1 / S500 / S550 / YPT410 / S650 / E453
DC20A	DC20A-PURP	DGX 505 / DGX520 / DGX530 / DGX630 / DGX640
DC21A	DC21A-PURP	E202 / 213 / 223 / 233 / 243 / 303 / 310 / 313 / 320 / 323 / 343 / 350 / 420 / 550 / 225 / 220 / 230 / 290 / 350 / 353 / EZ200 / EZ220 / YPT210 / YPT220 / YPT230 / YPT240 / A350 / R200
DC22A	DC22A-PURP	DGX620 / DGX640 / DGX650 / YPG635
DC23A	DC23A-PURP	CP33
DC23B	DC23B-PURP	CP1 / CP5
DC24A	DC24A-PURP	CP300
DC24B	DC24B-PURP	CP50
DC25A	DC25A-PURP	PSR S700 / S710 / S900 / S910 / S750 / S950 / S970 / A2000
DC26A	DC26A-PURP	MX49
DC27A	DC27A-PURP	MX61
DC28A	DC28A-PURP	MOX6 / MOXF6
DC29A	DC29A-PURP	MOX8 / MOXF8
DC30A	DC30A-PURP	MOTIF XS6 / ES6 / XF6 / MONTAGE 6
DC31A	DC31A-PURP	MOTIF XS7 / ES7 / XF7 / MONTAGE 7
DC32A	DC32A-PURP	MOTIF XS8 / ES8 / XF8 / MONTAGE 8
DC33A	DC33A-PURP	MM6
DC34A	DC34A-PURP	SO3SL
DC35A	DC35A-PURP	MO6
DC36A	DC36A-PURP	MO8
DC37A	DC37A-PURP	NP30 / NP31 / NP32
DC38A	DC38A-PURP	P35 / P85 / P95 / P105
DC39A	DC39A-PURP	NVP60 / NVP80
DC40A	DC40A-PURP	NP11 / NP12
DC41A	DC41A-PURP	CP4 / P255
DC42A	DC42A-PURP	EW300
DC43A	DC43A-PURP	EW400